


NOTES:

1. RESILIENT TILE SHALL MEET THE ASTM 8' CRITICAL FALL HEIGHT PER MANUFACTURE'S SPECIFICATIONS.
2. APPLY ADHESIVE COAT TO ENTIRE SURFACE PRIOR TO INSTALLING RESILIENT TILES; AND APPLY ADHESIVE TO EACH JOINT PER MANUFACTURE'S SPECIFICATIONS.
3. ENSURE SUBSOIL DRAINS TOWARDS PERFORATED DRAIN TUBING.
4. INSTALL PERFORATED DRAIN TILE AT 16" ON CENTER AS WELL AS AROUND THE PERIMETER OF RESILIENT TILE INSTALLATION.
5. BACK FILL AROUND PERFORATED DRAIN TILE WITH 1" WASHED STONE TO 6" RADIUS AROUND DRAIN TUBING. WRAP WITH FILTER CLOTH TO PERVENT THE STONE FROM OBSTRUCTING THE DRAIN.



SAFETY SURFACE (RESILIENT TILE - Granular Base)

The Maryland-National Capital Park and Planning Commission
Montgomery County Department of Parks

Detail No.

JULY 2007